



XL950 ComfortLink™ II Thermostat

*Amazingly versatile,
incredibly advanced*

*The ComfortLink™ II
thermostat integrates home
comfort into your personal
lifestyle like nothing you've
ever seen before.*



Features Include...

- Large Color Display
- Simple Programming
- Weather Forecast (via wireless home network)
- Allergy Clean/Quick Clean Cycles
- Interactive Touchscreen
- 1-Touch Presets
- Built-in Help Screens
- Operating Runtime Analysis
- System Alerts
- Lock Screen Security
- Custom Screen Options
- Screen Savers
- Five Year Limited Warranty

Easy to use

The simple design and easy to follow functions of this thermostat make it the most intuitive and easy to use thermostat available. Just touch the screen to try out the functionality and make operational changes to the system in your home.

Help System

On-screen notes provide additional details. When more information is needed, context sensitive help is only a button touch away.

Scheduling

Scheduling setup is made easy with the use of an on-screen wizard that walks you through the process.

1-Touch Presets

Cooling and Heating presets allow you to change your in-home temperatures with the touch of a button.

Customizable

Customize the screen to suit your unique needs. You can setup shortcuts and an easy access dashboard on the Home screen. You can change the colors, and enjoy a photo slideshow.

⚠ CAUTION

Use only your fingertips to touch the touchscreen. Using any other implement can damage the screen.

⚠ CAUTION

Use only a soft damp cloth to clean the screen.

Table of Contents

Introduction.....	1-4
Buttons and Navigations.....	5
System, Fan, & Air Cleaner Modes	6-7
Scheduling/Programming	8-9
Loading and Viewing Photos	10-11
Screen Saver Settings.....	12
Commonly Used Features.....	13
Naming your System	13
Dealer Information Screen.....	13
Setting Time and Date	14
Security Options	14
Runtime History.....	14
1-Touch Presets.....	14
Customize Your Home Screen.....	15
Humidity.....	15
Wireless Network Setup	16-19
Advanced Networking Information.....	20-23
Multi-System Control	24-25
Wireless Registration.....	26-27
Troubleshooting	28-29
Index.....	30
Warranty	31

Easy to use... Everything is just a touch away



1 Buttons and Navigation

Pressing a button will display additional information or a new menu screen.


EXAMPLE: You may access the **Menu** screen by pressing the “Menu” button on the home screen.



You may access the **Settings Menu** by pressing the “Settings” button from the **Menu** screen.



EXAMPLE: In the following sections, button sequences will be shown with icons. For example, the sequence on this page would be represented this way:



2 System ON/OFF, Mode Selection

To the right of the Menu button are 3 Mode buttons:

- 1) The first sets **System Mode** (including OFF).
- 2) The second controls **Fan Mode**.
- 3) The third controls **Air Cleaner Mode**.

Each button has mode options to choose from. The chosen mode is conveniently displayed on its home screen button so you can see the functions your system is performing.



Mode Selection

1) System Mode

The “Auto” System Mode will switch between heating and cooling automatically.

“Heating” and “Cooling” modes are dedicated modes. For example, you may wish to set your system to “Heating” in winter months so your cooling unit does not run. Likewise, you may wish to set your system to “Cooling” in summer months so that your furnace does not run.

To completely turn off your system, select “Off”.




2) Fan Mode

In “Auto” Fan Mode the system’s fan will run only when the system runs.

The fan will run continuously when the Fan Mode is set to “On”.

The “Circulate” Fan Mode will run the fan at least 10-55 minutes out of every hour, decreasing hot/cool spots throughout your house.



3) Air Cleaner Mode

Automatic means the air cleaner will run when the fan runs.


Quick Clean is a full power air cleaning cycle that increases the system fan speed setting (when not actively heating or cooling) to 100% for **three hours** to achieve maximum clean air delivery rate.

Allergy Clean is a full power air cleaning cycle that increases the system fan speed setting (when not actively heating or cooling) to 100% for **24 hours** to achieve maximum clean air delivery rate.




3 Set Point Panel

A Setpoint is the desired temperature you would like your home heated or cooled to when in one of the three System Modes.



To adjust the Heating Setpoint, select "Heating" and raise or lower the temperature to reach your desired setpoint.

Heating Setpoint Panel



To adjust the Cooling Setpoint, select "Cooling" and raise or lower the temperature to reach your desired setpoint.

Cooling Setpoint Panel




4 Manually Set up a Schedule

The procedure below describes setting up a manual schedule. Scheduling can also be set up via Guided Scheduling which creates a schedule by asking you a series of questions. Guided Scheduling can also be selected in the screen below.

1) Turn Scheduling On (and select Manual Scheduling)



2) Enter the Schedule Menu



3) Select a day or time period

By default the schedule shows the periods Wake, Away, Home and Sleep. Each day can have its own schedule and each schedule will be a unique color.

Default
Schedule



4) Select the days you would like to schedule

By selecting more than one day, you can set the schedule to be the same for those days. For example, you may keep the same hours each weekday.



5) Adjust the Time for each period

Select a period one at a time and set its beginning time by pressing the "Time" button.


Press the "Temperature" button to adjust the setpoints for each period.

NOTE: Notice that you can delete or add periods (maximum 6 per day).



6) Adjust the Temperature for each period

Press the "Temperature" button to adjust setpoints for each period.



7) Press "Apply" when complete

Finished Examples:


Example A:

Example A is for someone who works and is out of the house during weekdays.



Example B:

Example B is for someone who is out of town Monday–Thursday.




5 Using Photos

You can set up a photo album and a screen saver using your own photos.

Using an SD Card

Insert the SD Card at the bottom right hand side of the thermostat, taking care to keep the card's "notch" in the orientation shown.

NOTE: The card must remain inserted to view the photos and the SD card must remain "unlocked."



Recommended SD Cards:

SD, SDHC
SD Adapter – microSD, miniSD, microSDHC, mini SDHC

Required Photo Formats:

Photos on your SD card must be in .jpg, .jpeg, .bmp, .png, or .gif formats and each photo must be less than 3MB in file size.


Photo Album

View and set up your photo album.



Load and Select Photos

- 1) If you do not yet have your SD card inserted or it is not inserted all the way, you will see this message.



- 2) Images will be loaded from your SD card into the viewer and sized to fit the screen.



- 3) Browse the album using the arrows on the right and left edges of the screen. Touch the image to see full size images.



Check the "Add to Slideshow" box to include the a photo in a slideshow.

- 4) In thumbnail view, you can view up to 15 photos at time. You can also see or select which photos will be included in a slideshow.




- 5) After you have selected which photos to include in your slideshow, press "Settings" to configure the Screen Saver.


(Or navigate to the Screen Saver menu using the path on the next page.)

Screen Saver

A standard or a custom photo screen saver can be selected.




- 1) If your desire, turn "On" the screen saver. Set the wait time until the screen saver starts.



- 2) The "Default Screen Saver" shows the current temperature as a floating icon over a darkened black screen.

Select "Image Screen Saver" if you have inserted an SD card and added photos to a slideshow.




- 3) Set the number of seconds before the next photo will display.

6 Other Commonly Used Features

The following pages highlight some of the more common processes you will use.


Name Your System

Give your system a name. This is very important if you have more than one system in your home.




Events and Vacations

Set up how your system will operate for special events or when you are away from home for extended periods.



Dealer Information

Contact your dealer by using contact information in the Service menu.



Time & Date

Set time, date and time zone. If a wireless network is set up, the time can be automatically synced via the internet.



Security

Protect your system from accidental or unwanted changes to your system by using a PIN lock.



1-Touch Presets

Set up these presets to make quick temperature setpoint changes from the Home Screen.




System Runtime History

System Runtime History monitors how much your system runs for both heating and cooling and also displays the average indoor temperature and outdoor high and low temperatures. This data allows you to better manage your utility costs by seeing when and how much your system is operating.

Customize your Home Screen

Add shortcuts and customize the dashboard...




Wireless Network Setup

Set up a connection to your wireless network to enable weather and software update features. See Section 6 for setup-details (802.11 B/G wireless router and internet required).



Humidity

You may see and adjust the humidity level in your home and adjust the humidity setpoints for both Heating and Cooling modes (for systems equipped with humidity control).



7 Optional Wireless Networking

Enabling wireless networking brings additional functionality to your thermostat.

IMPORTANT:

After wireless networking is enabled, you will need to register your system with a valid email address before the weather data will be displayed.

NOTE: On a normally configured network, familiarity with a personal wireless network is helpful but not necessarily required for installation.

If your personal wireless network is a secure network, you will need the password.

1. Your thermostat can access real-time weather conditions, forecasts and alerts.



2. When you have multiple systems in your home, each thermostat can see and control the others.

NOTE: In a Multi-System environment, it is recommended to name each thermostat before enabling wireless networking.




3. You can download software updates for efficient operation and the ability to use new features as soon as they are released.



7.1 Enabling Wireless Networking


1) Enter the Wireless Network Setup Menu...



2) Enable the wireless radio by pressing "Wireless ON/OFF".







3) After the wireless radio is enabled, press the "Connect to a Network" button to choose from a list of available wireless networks.



NOTE: If the router is configured to not broadcast its SSID, refer to Advanced Network Settings.

7.2 Selecting a Network



Signal Strength Indicators		
Indicator	Bars (Color)	Description
	One (Red)	Very Weak
	Two (Yellow)	Weak
	Three (Green)	Strong
	Four (Green)	Very Strong



Available broadcasting networks with an adequate signal strength will display their SSIDs (Service Set Identifiers) in this screen.

A closed lock icon next to the SSID indicates a secure network. An open lock indicates a non-secure, “open” network.

Select your network and press “Connect”.

The signal strength is indicated in bars. The more bars, the better the signal strength.


A minimum of three bars is required for stable network operation. The network will operate with one or two bars, but may result in intermittent or lost connections.

NOTE: Signal strength may be affected by router model, interference, obstructions and distance from the router. Consult router documentation for additional information.


If a “Network Not Found” message is displayed, verify the wireless network is functioning and within range. Consult router documentation for additional information.

7.3 Enter Network Key/Password

1A) If the network is unsecured (with an “open” padlock), the following message will be displayed.



1B) If the network is secured (with a “closed” padlock), the following message will be displayed.



2) Enter the network key (case-sensitive password). You or your network administrator will need to provide the required information.



3) The thermostat will connect to the wireless network.




4) When the thermostat has successfully joined the wireless network, the name of the network will be displayed with a green dot to the left and a signal strength indicator to the right.



7.4 Advanced Networking Information

1) Enter the Advanced Network Setup Menu...



Advanced networking will be required in the following two instances:

1. When connecting to a non-broadcast network
2. When configuring a static IP address

IMPORTANT:

The **Advanced Network** screens are intended for individuals with networking familiarity.

You or your network administrator will need to provide the required information.

If any of this information is unknown or for questions specific to the wireless router, please consult the router documentation or your network administrator.

7.5 Network Security

When the network's SSID is not broadcast (hidden), manual configuration in this screen is required.



1) The “Network Security” button in this **Advanced Network Settings** menu will be highlighted by default.



2) Press the “Enter SSID Name” button.



3) Enter the SSID Name using the on-screen keypad.



4) Select a network security type.



5) Press “Enter Network Key” button.



6) Enter the Network Key using the on-screen keypad.

7.6 Host Settings

This screen is used to control how the thermostat obtains network addresses and is needed when DHCP (Dynamic Host Configuration Protocol) has been turned off or is not available on the router. Otherwise, you may use DHCP to automatically obtain this information. This manual configuration is required if a static IP address is desired.

NOTE: No additional configuration may be required in a non-broadcast network where IP addresses are assigned by DHCP. You may Connect to the network without modifying the Host Settings.



1) Select the “Host Settings” button to access the second screen of settings in this **Advanced Network Settings** menu.



2) Select IP Address, Gateway and Subnet Mask buttons as required.



3) Enter the IP address(es) as required for each.



4) To manually select a DNS server, enter IP address(es).




5) After all the addresses are assigned, Connect to the network.



6) To change a Static IP Address to a DHCP Address, press “Release and Renew IP Address”.

7.7 Network Properties



The **Network Properties** screen displays the thermostat's current network information.



7.8 Disconnecting from a Network

Once a network has been joined, the thermostat will reconnect to it after signal or power interruptions. When connected, a green dot will be shown.


To disconnect from this network, enter the "Connect to a Network" menu and select "Disconnect".

NOTE: When joining a different network, the current router must be disconnected in this menu before a new one may be selected. In addition if settings are changed on the owner's router, the network may need to be disconnected and reconnected in this menu.

Repeat previous steps to connect to a different network.



7.9 Multi-System Environments



- 1) In a multi-system environment each thermostat can see and control the others.

NOTE: The thermostats must have wireless enabled and be connected to the same personal wireless network.



- 2) Each thermostat belongs to an Access Control Group—set to “Group A” by default. Therefore, if two thermostats are connected to the same wireless network and have matching Group IDs (shown as Group A to the right), they will be able to communicate with each other.

Set the thermostat(s) to the desired Group.



Multi-System Environments (Continued)

- 3) In a multi-system environment where the systems are in the same Group, the “Zones” button will appear in place of the “System” button (see picture at right).

Pressing the “Zones” button opens the Zone Menu.



- 4) The Zone Menu is shown at right.

- 5) The Zone Overview menu shows a quick view of each zone’s current condition.

- 6) System and Zone Names may be set in the Zone Names screen. The “Rename System” and “Rename Zone” buttons allow entering custom names from a keypad.

The “Select Zone Name” and “Select System Name” buttons allow selecting pre-configured names from a list.



- 7) In multi-system environments, the main screen display will change to indicate the presence of multiple zones. (Notice the new zone button—labeled “Upstairs”—at right.)

The arrow buttons on either side of this displayed zone name will allow viewing of the other zone setting screen(s) one at a time.




8 Wireless Registration

Registration is required for Weather, Software Updates and linking two or more thermostats together. Registration ensures that your thermostat is using the most up-to-date software and will also let you take advantage of exciting new features in the future. You will be notified by email when there is a software update. For complete privacy information see our Privacy Policy at trane.com.


- 1A) In the Network Setup Screen, select the "Register Now" button to begin registration. Proceed to Step 2.



- 2) Read and accept the License Agreement to proceed with the Registration process.




- 1B) If instead you try to connect to Weather before you have registered, you will be prompted to register.




- 3) The E-mail Registration screen explains that after entering an address, you will receive a verification code via email.




- 5) Enter a valid email address, press “Apply” to proceed.




- 6) The thermostat will connect to a remote server.



- 7) After connecting to the server, an email will automatically be sent to your email address.




- 8) Check your email to find your 5-digit verification code.




- 9) Enter the 5-digit verification code.

NOTE: This will only need to be done one time.




- 10) After entering your verification code, your additional features will now be enabled.



9 Troubleshooting

“No System Found” displays on the screen...

Reboot your thermostat at the following location.




Slow or no response to any button presses...

Remove and replace the thermostat as shown below. The boot up process may take several minutes.

Remove Thermostat


Remove thermostat from its sub-base by grasping at edges and gently pulling the thermostat straight towards you. It should release without much effort.



Replace Thermostat

Replace thermostat flat onto sub-base being careful to align unit correctly with the sub-base before applying force.


Thermostat should fit snug and not “rock” when properly installed.



System Alerts

- 1) When your system indicates an issue with communication or operation, an alert will display on the screen.

Click the “Dealer Contact Info” to retrieve phone numbers and website information



- 3) Press “Close” to dismiss the alert. It can be recalled by pressing the Alert icon in the menu bar.




- 2) Contact your dealer.



- 4) The Alert icon will remain in the menu bar.



Dealer Information can also be accessed by this path:



Index of Functionality

1-Touch Presets.....	14
Air Cleaner Mode.....	7
Alerts	29
Customize Home Screen.....	15
Dealer Information	13
Events.....	13
Fan Mode.....	6
Humidity.....	15
Multi-System.....	24
Name System	13
Network	18
Network Key	19
Photo Album	10
Registration	26
Scheduling.....	8
Screen Saver	12
Security	14
System Mode.....	6
System ON/OFF	6
System Runtime History.....	14
Time/Date	14
Troubleshooting	28
Wireless Networking.....	16

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

(1) Reorient or relocate the transceiver antenna. (2) Increase the separation between the equipment and transceiver. (3) Connect the equipment into an outlet on a circuit different from that to which the transceiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules and Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC/IC Caution: Any changes or modifications not expressly approved by Trane could void the user's authority to operate this equipment.

Important Note: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device. This device has been designed to operate with an internal PCB trace antenna.

To comply with IC RF exposure limits for general population/uncontrolled exposure, the module with fixed internal antenna must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

TRANE U. S. INC.
MODEL NUMBER
TZONE950AC52Z

FCC ID: XVRZONE950TRX
IC: 6178D-ZONE950TRX

Limited Warranty

This limited warranty is extended by the manufacturer to the original purchaser and to any succeeding owner of the real property to which the low voltage room comfort control is originally affixed and applies to products purchased and retained for use within the U.S.A. and Canada. The limited warranty period begins when the low voltage room comfort control installation is complete, verified by installer's in voice or similar document. If installation completion and start-up date cannot be verified by installer's invoice or similar document, limited warranty coverage begins six (6) months after the date of manufacture based on the low voltage room comfort control serial number. If any part of your low voltage room comfort control fails because of a manufacturing defect within five (5) years from the date the limited warranty period begins, Warrantor will furnish without charge a new low voltage room comfort control. Any local transportation, related service labor, and diagnosis calls, are not included. This limited warranty does not apply if the low voltage room comfort control was purchased direct (i.e. from internet websites or auctions) on an uninstalled basis. Additionally, this limited warranty will not apply unless the low voltage room comfort control is: (1) installed by a licensed or qualified HVAC technician, (2) applied and installed in accordance with the manufacturer's recommendations in its Installer's Guide, and (3) in compliance with all industry standards, national, state, and local codes.

This limited warranty does not cover your low voltage room comfort control if it is damaged while in your possession; including, but not limited to (1) damage caused by unreasonable use of the low voltage room comfort control, (2) damage from failure to properly maintain the low voltage room comfort control as set forth in the Use and Care manual, (3) damage that is not considered a manufacturing defect, such as acts of God, malfunctions or failures resulting from fire, water, storms, lightning, earth quake, theft, riot, misuse, abuse, increased utility usage costs, (4) performance problems due to improper selection/equipment match-up, installation, or application, or (5) failures, defects, or damages (including, but not limited to, any failure or loss of data) caused by any third party product, service, or system connected or used in conjunction with your low voltage room comfort control. THE LIMITED WARRANTY AND LIABILITY SET FORTH HEREIN ARE IN LIEU OF ALL OTHER WARRANTIES AND LIABILITIES, WHETHER IN CONTRACT OR IN NEGLIGENCE, EXPRESSED OR IMPLIED, IN LAW OR IN FACT, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR USE, AND IN NO EVENT SHALL WARRANTOR BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow limitations on how long an implied limited warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Parts will be provided by our factory organization through an authorized service organization in your area listed in the yellow pages. If you wish further help or information concerning this limited warranty, contact:

Residential Systems, 6200 Troup Highway, Tyler, TX 75707.
Attention: Consumer Relations
Or visit our website: www.trane.com/residential
TW-1019-5109



TRANE®

6200 Troup Highway
Tyler, TX 75707
© 2011 Trane



03/11 32-5070-01

The manufacturer has a policy of continuous product and product data improvement and it reserves the right to change design and specifications without notice.